

sani⁺SWISS

SAFE HYGIENE SOLUTIONS

SANISWISS SANIPOD

- + IMPROVES COMPLIANCE
- + IMPROVES AVAILABILITY
- + SHARES BEST PRACTICES



SAFE™

SANISWISS SA | [SANISWISS.COM](https://www.sanisswiss.com) | [INFO@SANISWISS.COM](mailto:info@sanisswiss.com) | SWITZERLAND

THE IMPORTANCE OF HAND HYGIENE

CHALLENGE

For years now, Hand Hygiene has been recognized as the most important tool in preventing the spread of healthcare-associated infections (HAI). Indeed, through compliant Hand Hygiene practices - cleaning hands at the right time and the right way - most HAI are preventable. Nevertheless, in 2019 studies are still showing evidence of poor compliance rate amongst Healthcare Workers (HCW), with an overall average of 38.7 % with lower rates for Doctors than Nurses. Therefore, there is still a lot to achieve in order to prevent HAI from Hand Hygiene, and that is why Saniswiss is a member of the Private Organizations for Patient Safety (POPS), a program which was launched by WHO with one aim: promoting Hand Hygiene Guidelines to increase Patient Safety on a global scale. All around the world, Saniswiss increases awareness and shares WHO's recommendations and tools with its team of trained qualified professionals to better serve our customers and their patients' safety.

SOLUTIONS

At Saniswiss, we believe that in regard to Hand Hygiene, IPC managers should never compromise on quality and always look for "tolerance for compliance". Indeed, we believe that in addition to the multi-modal strategy from WHO, the key to increase compliance in Hand Hygiene practices, and therefore reducing HAI, is to offer healthcare workers products which respects their skin, their health, and their environment. We offer a complete range of products safe for healthcare workers' health and environment which are all SAFE certified.



HOW TO
ENSURE
AN OPTIMAL
HAND HYGIENE
COMPLIANCE



SANISWISS INNOVATION

Developed with healthcare workers for healthcare workers, the Sanipod encompasses WHO's multimodal approach to Hand Hygiene. Providing instant trainings with immediate feedbacks, it also alerts distinctively facility managers when the Sanipod is empty, to improve hand sanitizers availability drastically. Touchless, airless and with a safety cover, its large autonomy allows for up to 20'000 disinfections. With its one-of-a-kind organic design, it reflects the commitment for hand hygiene excellence from ambitious healthcare stakeholders.

SANISWISS SANIPOD | REF. 132184

TECHNICAL DATA		
SUITABILITY	Sanitizer Hands H1 Gel REF. 132151	
INSTALLATION	Easy to set up, wall-mounted installation or use with floor stand	
CAPACITY	800 mL reservoir pouch	
BATTERY LIFE	4 x standard size C batteries* 20'000 uses	
DIMENSIONS	280 L x 295.4 H x 159 D mm	

OUR UNIQUE SOLUTION IN A NEW FORMAT

SANITIZER HANDS^{H1}

Formulated with bioethanol from organic origin. Efficient on most germs for hygienical as well as surgical disinfection. Good persistent activity after disinfection. Meet WHO recommendations on Hand Hygiene (POPS).



SANITIZER HANDS H1 | REF. 132151

- + BROAD SPECTRUM IN 30 SEC
- + NO ALLERGENIC SUBSTANCE
- + THIXOTROPIC GEL

ACTIVE AGAINST	ACCORDING TO STANDARDS
BACTERICIDE	EN 1500, EN 1040, EN 12791, EN 13727+A2
YEASTICIDE	EN 1650, EN 13624, EN 1500, EN 12791
FUNGICIDE	EN 13624
MYCOBACTERICIDE	EN 14348
VIRUCIDE	EN 14476+A1 DW & RKI

HOW IT WORKS

Sanipod touch-free dispensing encourages better hand hygiene in an environment and is essential to help prevent infection. Saniswiss Sanipod dispenses Sanitizer Hands H1 hygienically without touching the unit and is perfect for use in all types of environments.



ONCE THE POUCH IS EMPTY, A RED LIGHT IS REFLECTED AGAINST THE WALL



UNSCREW THE COVER ON THE RIGHT



CHANGE THE POUCH AND SCREW THE COVER BACK



FEATURED ACCESSORY

SANIPOD STANDALONE

The high quality aluminum stand with steel base can be placed anywhere where hand sanitization is needed.

With its sleek design, the curved back panel and base prevents the floor from getting dirty and catches any falls. Get this practical Sanipod column for hand disinfection without wall mounting.

SANISWISS SANIPOD STANDALONE | REF. 132185

- + UNIQUE DESIGN
- + ROBUST MATERIALS
- + DRIP FREE DESIGN

TECHNICAL DATA		
MATERIAL	Steel and aluminum	
COLOR	Pure white	
DIMENSIONS	139 cm (H) X 45 cm (D) X 26 cm (W)	
WEIGHT	12 kg	
CONTENTS	4 screws + 4 wall fittings	

SECONDS SAVE LIVES

With the ambition of providing hand hygiene amongst healthcare workers at heart, we proudly introduced this year a brand-new way to dispense our best-in-class Sanitizer Hands H1 : the Sanipod. With its unique design, it brings several innovations for the improvement of touch-less Hand Hygiene compliance. Its smart backlight offers key visual insights for Healthcare workers such as the 6 movements of Hand Hygiene as for WHO's recommendations.



6 MOVEMENTS FOR A BETTER HAND HYGIENE COMPLIANCE



1. RUB HANDS PALM TO PALM



2. RIGHT PALM OVER LEFT DORSUM WITH INTERLACED FINGERS AND VICE VERSA



3. PALM TO PALM WITH



4. BACKS OF FINGERS TO OPPOSING PALMS WITH FINGERS INTERLOCKED



5. ROTATIONAL RUBBING OF LEFT THUMB CLASPED IN RIGHT PALM



6. ROTATIONAL RUBBING, BACKWARDS AND FORWARDS WITH CLASPED FINGERS OF RIGHT HAND IN LEFT PALM AND VICE VERSA